


BIS ARAYTUB

Assembly instruction



DE Montageanleitung
 NL Montage-instructie
 FR Instructions de montage
 ES Instrucciones de montaje





PL Instrukcja montażu
 CS Montážní návod
 RU Инструкция по монтажу



For massive and hollow materials



DE für massive und hohle Materialien
 NL voor massieve en holle materialen
 FR pour matériaux pleins et creux
 ES para materiales macizos y huecos
 PL dla materiałów pełnych i komórkowych
 CS pro plně a duté materiály
 RU для монолитных и полых материалов

#	Ø		
0850 6 116	16 mm	200 x	1 x
0850 6 120	20 mm	200 x	1 x
0850 5 125	25 mm	100 x	1 x



Also available:

DE Auch lieferbar:
 NL Ook leverbaar:
 FR Aussi disponible:
 ES También disponible:
 PL Dostępne także:
 CS Také dostupné:
 RU также поставляется:

#	Ø		
0850 3 116	16 mm	25 x	-
0850 3 120	20 mm	25 x	-
0850 3 125	25 mm	25 x	-
0850 5 216	16 mm	100 x	1 x
0850 5 220	20 mm	100 x	1 x
0850 5 225	25 mm	100 x	1 x

