





Instructions for use Walraven S-LF



#	D (mm)	DN	D (")	G	VdS*	FMs**
45555028	26.9	3/4	20	M8	VdS	-
45555035	33.7	1	25	M8	VdS	-
45555044	42.4	1 1/4	32	M8	VdS	-
45555050	48.3	1 1/2	40	M8	VdS	-
45555062	60.3	2	50	M8	VdS	-
45565035	33.7	1	25	M10	VdS	FM
45565044	42.4	1 1/4	32	M10	VdS	FM
45565050	48.3	1 1/2	40	M10	VdS	FM
45565062	60.3	2	50	M10	VdS	FM
45565077	76.1	2 1/2	65	M10	VdS	FM
45565090	88.9	3	80	M10	VdS	FM
45565115	114.3	4	100	M10	VdS	FM
45565142	139.7	5	125	M12	VdS	FM
45565170	168.3	6	150	M12	VdS	FM
45565221	219.1	8	200	M16	VdS	FM

* Installation must be carried out according to VdS requirements

** Installation must be carried out according to FM Global data sheet 2-0

Always install according to local regulations

J. van Walraven Holding B.V., Industrieweg 5, 3641 RK Mijdrecht, The Netherlands